

Push knobs 按盤鈕 (按鍵)

Description

- Material: ABS
- Shaft hole: 3.3 x 3.3 mm

說明

- 材質: ABS
- 插梢尺寸: 3.3 x 3.3 mm

PART NO.	DIA	HEIGHT	FINISH	HOLE
48001-2	6.0	9.0	TEXTURE	2.8X2.8
48001-5	8.8	10.7	GLOSSY	3.3X3.3
48001-8	10.0	15.4	GLOSSY	3.3X3.3
48001-10	9	14.4	GLOSSY	3.3X3.3




Description

- Material: ABS with aluminum shell
- Shaft hole: 3.3 x 3.3 mm

說明

- 材質: ABS+鋁殼
- 插梢尺寸: 3.3 x 3.3 mm

PART NO.	DIA	HEIGHT	FINISH
48002-1	8.9	14.0	NATURAL
48002-2	8.9	14.0	BLACK
48002-3	9.0	13.7	NATURAL
48002-4	9.0	13.7	BLACK
48002-5	10.5	16.2	NATURAL
48002-6	10.5	16.2	BLACK




Description

- Material: ABS
- Shaft hole: 3.3 x 3.3 mm

說明

- 材質: ABS
- 插梢尺寸: 3.3 x 3.3 mm

PART NO.	L	W	H
48003-1	6	6	8.2
48003-2	8	8	5.2
48003-3	12	12	10
48003-4	15	7.2	10.6
48003-5	15.3	6.3	12
48003-6	18.2	7.8	13.7
48003-7	6	6	7.5



Description

- Material: ABS
- Shaft hole: 6 x 1.6 mm

說明

- 材質: ABS
- 插梢尺寸: 6 x 1.6 mm

PART NO.	L	W	H
48004	14.8	14.8	5.6



Description

- Material: ABS
- Shaft hole: \varnothing 3.0 mm

說明

- 材質: ABS
- 插梢尺寸: \varnothing 3.0 mm

PART NO.	DIA	H	finish
48005	6	14.5	black

