


Slide control knobs 滑鈕

45001

Description

- Material: ABS
- Paint fill indicator line
- Color: Black, Green, Red, Chromed plated

- 材質: ABS
- 劃漆指示線
- 顏色: 黑, 綠, 紅或電鍍





45002

Description

- Material: ABS chrome plated
- Paint fill red indicator

- 材質: ABS 塑膠電鍍
- 劃漆指示線




45003

Description

- Material: ABS
- Color: Top is chromed plated, bottom is black
- Black indicator
- Glue assembled

- 材質: ABS
- 顏色: 上部電鍍
底部黑色
- 黑色指示線
- 上膠組合




45004

Description

- Material: ABS

- 材質: ABS




45005

Description

- Material: ABS plastic with chrome plated


- 材質: ABS 塑膠電鍍



Slide control knobs 滑鈕



45012
With paint filled indicator line
指示線劃漆
25(L) x 15(W) x 9.6(H) mm
Shaft hole: 3.5 x 1.1 mm



45013
With paint filled indicator line
指示線劃漆
24.2(L) x 13(W) x 10.7(H) mm
Shaft hole: 4 x 1 mm



45015
With paint filled indicator line, knurling on two sides, glossy finish
亮面, 指示線劃漆, 兩側直齒狀
20.2(L) x 7.2(W) x 7.2(H) mm
Shaft hole: 3.7 x 1.0 mm



45016
Glossy finish with paint filled indicator line
亮面, 指示線劃漆
14(L) x 9.7(W) x 10.4(H) mm
Shaft hole: 4.2 x 1.1 mm



45018
With paint filled indicator line
指示線劃漆
16.2(L) x 10.1(W) x 8(H) mm
Shaft hole: 3.8 x 1.6 mm



45019
Light texture with paint filled indicator line
淺咬花表面, 指示線劃漆
21(L) x 12.1(W) x 19.4(H) mm
Shaft hole: 3.5 x 1.1 mm



45023
ABS, light texture
ABS材質, 淺咬花
14.8(L) x 7.4(W) x 5.7(H) mm
Shaft hole: 6 x 1.6 mm



45026
PP+TPR, 咬花表面, 軟膠
25.8(L) x 11(W) x 10(H) mm
Shaft hole: 4 x 1.2 mm